

## Abnomal Test

Manufacturer : COSEL CO., LTD.

Tested Model [機種名]: YS1512U/YS1512A

Input Ratings [入力定格] :

Voltage AC 100-120 V

Frequency 50-60 Hz

Current                    0.4            A

Output Ratings [出力定格] :

Voltage	12	V	Current	1.3	A
---------	----	---	---------	-----	---

---

V
A

\_\_\_\_\_ V \_\_\_\_\_ A

\_\_\_\_\_ V \_\_\_\_\_ A

\_\_\_\_\_ V \_\_\_\_\_ A

V

Conducted by [試験担当]: S. Ito

Reviewed by [照査]: Y. Tanno

## Abnormal Test [アブノーマル試験]

Rated Input Current: 0.4A, Rated Output Voltage: 12V

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
1	C1	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	F1 Opened
2		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
3	C3	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	F1 Opened
4		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.2	12V →10V	
5	C4	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted F1 Opened
6		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
7	C5	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
8		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
9	C6	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
10		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
11	C7	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
12		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
13	C8	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
14		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
15	C10	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
16		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
17	C11	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,19 Opened
18		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.05	12V →7V	
19	C13	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.05	12V →0V	
20		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
21	C14	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.05	12V →0V	
22		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
23	C17	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.05	12V →0V	
24		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
25	C18	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.05	12V →0V	
26		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
27	C19	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.05	12V →0V	
28		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
29	C20	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	12V →10V	
30		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
31	C21	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
32		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
33	C26	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
34		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
35	C27	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.05	12V →0V	
36		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
37	D1	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
38		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
39	D2	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
40		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
41	D5	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
42		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
43	D13	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
44		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
45	D20	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.05	12V →7V	
46		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
47	D30	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.1	12V →2V	
48		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Current	Output Voltage	Comment [コメント]
49	IC1	A-R S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.5	12V →14V	
50		A-K S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.1	12V →2V	
51		R-K S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.5	12V →14V	
52		R OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.5	12V →14V	
53		A OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.5	12V →14V	
54		K OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.5	12V →14V	
55	L1	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
56		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
57	L2	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
58		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
59	PC1	C-E S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.1	12V →2V	
60		C, E OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.5	12V →14V	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または熔融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
61	PC1	A-K S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.5	12V →14V	
62		A, K OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.5	12V →14V	
63	R3	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
64	R5	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
65	R6	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
66	R7	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
67	R8	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
68	R9	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
69	R10	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
70	R11	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
71	R12	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
72	R14	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または熔融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
73	R15	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
74	R16	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
75	R17	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
76	R18	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
77	R19	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
78	R27	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
79	R28	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
80	R30	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
81	R31	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
82	R41	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shprted R18,R19 opened
83	SS1	+ OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
84		- OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	



No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
85	SS1	~ OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
86		+++ S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	F1 Opened
87		+~ S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	F1 Opened
88		--- S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	F1 Opened
89	SS2	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
90		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
91	T1	5-A S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
92		5, A OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
93		7-9 S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
94		7, 9 OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
95		9-8 S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
96		9, 8 OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
97	T1	9-10 S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
98		9,10 OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
99		2-3 S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
100		2,3 OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
101	TR1	E OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
102		B OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
103		C OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
104		C-E S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
105		C-B S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
106		B-E S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
107	TR3	E OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
108		B OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
109	TR3	C OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
110		C-E S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
111		C-B S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
112		B-E S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
113	ZD1	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.2	12V →7V	
114		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
115	ZD2	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.1	12V →2V	
116		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
117	ZD4	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
118		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
119	ZD5	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
120		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	

Compliance [判定] : ☒ Yes [合] / ☐ No [否]