

Abnormal Test

Manufacturer : COSEL CO., LTD.

Tested Model [機種名] : YW1515U/YW1515A

Input Ratings [入力定格] :

Voltage AC 100-120 VFrequency 50-60 HzCurrent 0.4 A

Output Ratings [出力定格] :

Voltage	<u>+15</u>	V	Current	<u>0.5</u>	A
	<u>-15</u>	V		<u>0.5</u>	A
		V			A
		V			A
		V			A

Conducted by [試験担当] : S. OrtoReviewed by [照査] : Y. Tano

## Abnormal Test [アブノーマル試験]

Rated Input Current: 0.4A, Rated Output Voltage: ±15V

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
1	C1	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	F1 Opened
2		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
3	C3	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	F1 Opened
4		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.2	±15V →±11V	
5	C4	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted F1 Opened
6		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
7	C5	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
8		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
9	C6	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
10		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
11	C7	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
12		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
13	C8	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
14		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
15	C10	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
16		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
17	C11	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, 19 Opened
18		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.05	±15V →±9V	
19	C13	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
20		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
21	C17	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.05	±15V →0V	
22		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
23	C18	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.05	±15V →0V	
24		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
25	C20	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	$\pm 15V$ $\rightarrow \pm 12V$	
26		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
27	C21	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
28		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
29	C24	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.05	$\pm 15V$ $\rightarrow 0V$	
30		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
31	C25	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.05	$\pm 15V$ $\rightarrow 0V$	
32		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
33	C26	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
34		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
35	C34	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
36		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
37	D1	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
38		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
39	D2	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
40		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
41	D5	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
42		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
43	D20	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.05	$\pm 15V$ $\rightarrow \pm 9V$	
44		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
45	IC1	A-R S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.5	$\pm 15V$ $\rightarrow \pm 19V$	
46		A-K S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.1	$\pm 15V$ $\rightarrow \pm 2V$	
47		R-K S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.5	$\pm 15V$ $\rightarrow \pm 19V$	
48		R OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.5	$\pm 15V$ $\rightarrow \pm 19V$	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
49	IC1	A OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.5	$\pm 15V$ $\rightarrow \pm 19V$	
50		K OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.5	$\pm 15V$ $\rightarrow \pm 19V$	
51	L1	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
52		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
53	L2	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
54		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
55	L3	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
56		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
57	PC1	C-E S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.1	$\pm 15V$ $\rightarrow \pm 2V$	
58		C, E OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.5	$\pm 15V$ $\rightarrow \pm 19V$	
59		A-K S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.5	$+15V$ $\rightarrow \pm 19V$	
60		A, K OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.5	$+15V$ $\rightarrow \pm 19V$	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
61	R3	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
62	R5	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
63	R6	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
64	R7	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
65	R8	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
66	R9	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
67	R10	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
68	R11	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
69	R12	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
70	R14	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
71	R15	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
72	R16	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
73	R17	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
74	R18	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
75	R19	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
76	R27	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
77	R28	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
78	R30	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
79	R31	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
80	R41	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
81	SS1	+ OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
82		- OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
83		~ OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
84		+- S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	F1 Opened

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
85	SS1	+～ S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	F1 Opened
86		--～ S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	F1 Opened
87	SS2	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
88		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
89	SS3	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
90		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
91	SS5	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
92		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
93	SS6	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
94		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
95	T1	5-A S/C	<input type="checkbox"/> Yes [有] <input type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
96		5,A OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
97	T1	7-9 S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
98		7, 9 OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
99		9-8 S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
100		9, 8 OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
101		9-10 S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
102		9, 10 OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
103		2-4 S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
104		2, 4 OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
105		1-3 S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
106		1, 3 OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
107	TR1	E OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
108		B OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
109	TR1	C OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
110		C-E S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
111		C-B S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
112		B-E S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
113	TR3	E OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
114		B OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
115		C OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
116		C-E S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
117		C-B S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
118		B-E S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
119	ZD1	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.2 →±8V		
120		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
121	ZD2	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.1	±15V →±3V	
122		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
123	ZD3	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
124		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.5	±15V →±19V	
125	ZD4	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
126		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
127	ZD5	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
128		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
129			<input type="checkbox"/> Yes [有] <input type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input type="checkbox"/> No [無]			
130			<input type="checkbox"/> Yes [有] <input type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input type="checkbox"/> No [無]			
131			<input type="checkbox"/> Yes [有] <input type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input type="checkbox"/> No [無]			
132			<input type="checkbox"/> Yes [有] <input type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input type="checkbox"/> No [無]			

Compliance [判定] :  Yes [合] /  No [否]