

## ABNORMAL TEST RESULT

## OF MODEL LEA100F

1. Did Cheese Cloth or Paper Glow?

No.

2. Did Ground Fuse Open?

No.

3. Dielectric breakdown?

No.

4. Other Results?

See the following pages .

( FMEA : 2/19 ~ 16/19)

( Abnormal Test Result: 17/19 ~ 19/19)

There was no emission of flame, molten metal, ignition of cheesecloth, dielectric breakdown, opening of the ground fuse, other indication of a shock or fire hazard.

## F M E A

Component	Mode	Comment	Output Voltage
C101	Open	Normal operation.	
	Short	F101 opened, No hazard.	0V
C102	Open	Normal operation.	
	Short	F101 opened, No hazard.	0V
C103	Open	See 17 Page.	
	Short	F101 opened, No hazard.	0V
C108	Open	Normal operation.	
	Short	No Hazard.	0V
C109	Open	Normal operation.	
	Short	No Hazard.	0V
C110	Open	Normal operation.	
	Short	Normal operation.	
C111	Open	See 17 Page.	
	Short	No Hazard.	0V
C112	Open	See 17 Page.	
	Short	See 17 Page.	
C113	Open	Normal operation.	
	Short	No Hazard.	0V
C114	Open	Normal operation.	
	Short	Normal operation.	
C115	Open	F101 opened, No hazard.	0V
	Short	No Hazard.	0V
C116	Open	Normal operation.	
	Short	No Hazard.	0V

F M E A

Component	Mode	Comment	Output Voltage
C117	Open	Normal operation.	
	Short	No Hazard.	0V
C118	Open	Normal operation.	
	Short	Normal operation.	
C119	Open	See 17 Page.	
	Short	F101 opened, No hazard.	0V
C201	Open	See 17 Page.	
	Short	No Hazard.	0V
C202	Open	Normal operation.	
	Short	Normal operation.	
C203	Open	See 17 Page.	
	Short	No Hazard.	0V
C204	Open	Normal operation.	
	Short	Normal operation.	
C205	Open	No Hazard.	Decreased
	Short	Normal operation.	
C206	Open	Normal operation.	
	Short	Normal operation.	
C207	Open	Normal operation.	
	Short	Normal operation.	
C208	Open	Normal operation.	
	Short	Normal operation.	
C501	Open	Normal operation.	
	Short	Normal operation.	

## F M E A

Component	Mode	Comment	Output Voltage
C502	Open	Normal operation.	
	Short	Normal operation.	
C503	Open	Normal operation.	
	Short	Normal operation.	
C504	Open	Normal operation.	
	Short	Normal operation.	
C505	Open	Normal operation.	
	Short	Normal operation.	
C506	Open	Normal operation.	
	Short	Normal operation.	
C507	Open	-5, -12, -15: Normal operation. -24: See 17 Page.	
	Short	No Hazard.	0V
C508 Except -24	Open	Normal operation.	
	Short	No Hazard.	0V
C510	Open	No Hazard.	Decreased
	Short	No Hazard.	Decreased
C511 Only -5	Open	No Hazard.	Decreased
	Short	No Hazard.	Decreased
D103	Open	No Hazard.	0V
	Short	Normal operation.	
D104	Open	Normal operation.	
	Short	Normal operation.	
D105	Open	Normal operation.	
	Short	Normal operation.	

## F M E A

Component	Mode		Comment	Output Voltage
D106	Open		See 17 Page.	
	Short		See 17 Page.	
D107	Open		See 17 Page.	
	Short		See 17 Page.	
D108	Open		Normal operation.	
	Short		No Hazard.	0V
D109	Open		Normal operation.	
	Short		Normal operation.	
D110	Open		Normal operation.	
	Short		Normal operation.	
D201	Open		No Hazard.	Decreased
	Short		Normal operation.	
D202	Open		No Hazard.	Decreased
	Short		Normal operation.	
D203	Open		Normal operation.	
	Short		No Hazard.	0V
D204	Open		Normal operation.	
	Short		Normal operation.	
IC101	Open	1	Normal operation.	
		2	Normal operation.	
		3	Normal operation.	
		4	Normal operation.	
		5	Normal operation.	
		6	Normal operation.	

F M E A

Component	Mode		Comment	Output Voltage
IC101	Open	7	F101 opened, No hazard.	0V
		8	No Hazard.	0V
		9	No Hazard.	0V
		10	F101 opened, No hazard.	0V
		11	Normal operation.	
		12	No Hazard.	0V
		13	F101 opened, No hazard.	0V
		14	Normal operation.	
		15	F101 opened, No hazard.	0V
		16	F101 opened, No hazard.	0V
	Short	1-2	No Hazard.	0V
		2-3	Normal operation.	
		3-4	No Hazard.	0V
		4-5	No Hazard.	0V
		5-6	No Hazard.	0V
		6-7	Normal operation.	
		7-8	No Hazard.	0V
		9-10	Normal operation.	
		10-11	No Hazard.	0V
		11-12	Normal operation.	
		12-13	No Hazard.	0V
		13-14	No Hazard.	0V
		14-15	F101 opened, No hazard.	0V
		15-16	F101 opened, No hazard.	0V

F M E A

Component	Mode		Comment	Output Voltage
IC201	Open	1	No Hazard.	0V
		2	No Hazard.	0V
		3	F101 opened, No hazard.	0V
		4	Normal operation.	
		5	Normal operation.	
		6	Normal operation.	
		7	Normal operation.	
		8	Normal operation.	
		9	Normal operation.	
		10	No Hazard.	0V
		11	No Hazard.	0V
		12	See 17 Page.	
		13	See 17 Page.	
		14	Normal operation.	
		15	Normal operation.	
		16	Normal operation.	
		17	No Hazard.	0V
		18	Normal operation.	
		19	Normal operation.	
		20	No Hazard.	0V
	Short	1-2	F101 opened, No hazard.	0V
		2-3	No Hazard.	0V
		3-4	Normal operation.	
		4-5	Normal operation.	

F M E A

Component	Mode		Comment	Output Voltage
IC201	Short	5-6	Normal operation.	
		6-7	Normal operation.	
		7-8	Normal operation.	
		8-9	Normal operation.	
		9-10	No Hazard.	0V
		11-12	No Hazard.	0V
		12-13	No Hazard.	0V
		13-14	Normal operation.	
		14-15	Normal operation.	
		15-16	Normal operation.	
		16-17	Normal operation.	
		17-18	Normal operation.	
		18-19	Normal operation.	
		19-20	No Hazard.	0V
IC501	Open	K	No Hazard.	0V
		A	No Hazard.	0V
		R	No Hazard.	0V
	Short	A-K	No Hazard.	Decreased
		K-R	No Hazard.	Decreased
		R-A	No Hazard.	0V
J201	Open		No Hazard.	0V
J501 Except -24	Open		Normal operation.	
J502	Open		No Hazard.	0V
L101	Open		No Hazard.	0V



# F M E A

Component	Mode		Comment	Output Voltage
L101	Short		Normal operation.	
L102	Open		No Hazard.	0V
	Short		Normal operation.	
L103	Open	1or7	No Hazard.	0V
		3or4	See 17 Page.	
	Short	1-7	F101 opened, No hazard.	0V
		3-4	See 17 Page.	
L104	Open		F101 opened, No hazard.	0V
L507	Open		See 17 Page.	
	Short		See 17 Page.	
PC201	Open	A, K	No Hazard.	0V
		C, E	No Hazard.	0V
	Short	A-K	No Hazard.	0V
		C-E	No Hazard.	0V
PC202	Open	A, K	Normal operation.	
		C, E	Normal operation.	
	Short	A-K	Normal operation.	
		C-E	No Hazard.	0V
R101	Open		Normal operation.	
R102	Open		Normal operation.	
R103	Open		Normal operation.	
R104	Open		Normal operation.	
R105	Open		Normal operation.	
R106	Open		No Hazard.	0V

## F M E A

Component	Mode	Comment	Output Voltage
R107	Open	No Hazard.	0V
R108	Open	No Hazard.	0V
R109	Open	See 17 Page.	
R110	Open	Normal operation.	
R111	Open	No Hazard.	0V
R112	Open	Normal operation.	
R113	Open	Normal operation.	
R114	Open	Normal operation.	
R115	Open	Normal operation.	
R116	Open	No Hazard.	0V
R117	Open	No Hazard.	0V
R118	Open	No Hazard.	0V
R119	Open	Normal operation.	
R120	Open	Normal operation.	
R121	Open	Normal operation.	
R122	Open	Normal operation.	
R123	Open	Normal operation.	
R124	Open	See 17 Page.	
R125	Open	See 17 Page.	
R126	Open	No Hazard.	0V
R127	Open	No Hazard.	0V
R128	Open	Normal operation.	
R129	Open	Normal operation.	
R130	Open	Normal operation.	

## F M E A

Component	Mode	Comment	Output Voltage
R131	Open	Normal operation.	
R132	Open	F101 opened, No hazard.	0V
R133	Open	Normal operation.	
R134	Open	Normal operation.	
R135	Open	Normal operation.	
R136	Open	Normal operation.	
R137	Open	Normal operation.	
R138	Open	No Hazard.	0V
R139	Open	Normal operation.	
R140	Open	Normal operation.	
R141	Open	Normal operation.	
R142	Open	Normal operation.	
R143	Open	No Hazard.	0V
R144	Open	No Hazard.	0V
R146	Open	Normal operation.	
R147	Open	Normal operation.	
R201	Open	Normal operation.	
R202	Open	Normal operation.	
R203	Open	Normal operation.	
R204	Open	Normal operation.	
R205	Open	Normal operation.	
R206	Open	No Hazard.	0V
R207	Open	No Hazard.	0V
R208	Open	See 17 Page.	

## F M E A

Component	Mode	Comment	Output Voltage
R209	Open	No Hazard.	0V
R211	Open	Normal operation.	
R212	Open	Normal operation.	
R213	Open	F101 opened, No hazard.	0V
R214	Open	Normal operation.	
R215	Open	No Hazard.	Decreased
R216	Open	Normal operation.	
R217	Open	No Hazard.	Decreased
R501	Open	Normal operation.	
R502	Open	Normal operation.	
R503	Open	No Hazard.	0V
R504	Open	Normal operation.	
R505	Open	No Hazard.	Decreased
R506	Open	No Hazard.	0V
R507	Open	No Hazard.	Decreased
R508	Open	No Hazard.	Decreased
R510	Open	Normal operation.	
R511	Open	Normal operation.	
R516	Open	Normal operation.	
R517	Open	Normal operation.	
R521	Open	Normal operation.	
R522	Open	Normal operation.	
R523	Open	Normal operation.	
R524	Open	Normal operation.	

F M E A

Component	Mode		Comment	Output Voltage
R525	Open		Normal operation.	
R526	Open		Normal operation.	
R527	Open		Normal operation.	
R528	Open		Normal operation.	
SK101	Open		Normal operation.	
	Short		F101 opened, No hazard.	0V
SS101	Open		No Hazard.	0V
	Short		F101 opened, No hazard.	0V
SS102	Open	Cathode	F101 opened, No hazard.	0V
		Alternative anodes	Normal operation.	
	Short		F101 opened, No hazard.	0V
SS501	Open	Forward side	See 17 Page.	
		Flyback side	See 17 Page.	
	Short	Forward side	See 18 Page.	
		Flyback side	See 18 Page.	
SS502 Except -24	Open	Forward side	See 18 Page.	
		Flyback side	See 18 Page.	
	Short	Forward side	See 18 Page.	
		Flyback side	See 18 Page.	
T201	Open	4or6	No Hazard.	0V
		2or3	F101 opened, No hazard.	0V
		8, 9or10, 11	No Hazard.	Decreased
	Short	4-6	F101 opened, No hazard.	0V
		2-3	F101 opened, No hazard.	0V

F M E A

Component	Mode		Comment	Output Voltage
T201	Short	8, 9-10, 11	No Hazard.	Decreased
TH101	Open		No Hazard.	0V
	Short		Normal operation.	
TR101	Open	C	No Hazard.	0V
		E	No Hazard.	0V
		B	No Hazard.	0V
	Short	C-E	Normal operation.	
		E-B	No Hazard.	0V
		B-C	Normal operation.	
TR102	Open	C	No Hazard.	0V
		E	No Hazard.	0V
		B	No Hazard.	0V
	Short	C-E	Normal operation.	
		E-B	No Hazard.	0V
		B-C	Normal operation.	
TR103	Open	D	Normal operation.	
		S	Normal operation.	
		G	Normal operation.	
	Short	D-S	See 18 Page.	
		S-G	Normal operation.	
		G-D	See 18 Page.	
TR104	Open	C	See 18 Page.	
		E	See 18 Page.	
		B	See 18 Page.	

## F M E A

Component	Mode		Comment	Output Voltage
TR104	Short	C-E	Normal operation.	
		E-B	See 18 Page.	
		B-C	Normal operation.	
TR105	Open	D	See 18 Page.	
		S	See 18 Page.	
		G	See 18 Page.	
	Short	D-S	See 18 Page.	
		S-G	See 18 Page.	
		G-D	See 18 Page.	
TR201	Open	D	See 18 Page.	
		S	See 18 Page.	
		G	See 18 Page.	
	Short	D-S	See 18 Page.	
		S-G	See 18 Page.	
		G-D	See 18 Page.	
ZD101	Open		No Hazard.	0V
	Short		Normal operation.	
ZD102	Open		Normal operation.	
	Short		Normal operation.	
ZD103	Open		See 19 Page.	
	Short		Normal operation.	
ZD104	Open		Normal operation.	
	Short		No Hazard.	0V
ZD501	Open		Normal operation.	

F M E A

Component	Mode	Comment	Output Voltage
ZD501	Short	No Hazard.	0V
ZD502 Only -24	Open	Normal operation.	
	Short	No Hazard.	0V



ABNORMAL TEST RESULT

Component	Mode		Comment	Output Voltage
C103	Open		Normal operation.	
C111	Open		No Hazard.	0V
C112	Open		Normal operation.	
	Short		Normal operation.	
C119	Open		F101 opened, No hazard.	0V
C201	Open		No Hazard.	0V
C203	Open		No Hazard.	0V
C507	Open		Normal operation.	
D106	Open		Normal operation.	
	Short		Normal operation.	
D107	Open		Normal operation.	
	Short		Normal operation.	
IC201	Open	12	No Hazard.	0V
		13	No Hazard.	Decreased
L103	Open	3or4	Normal operation.	
	Short	3-4	F101 opened, No hazard.	0V
L507	Open		F101 opened, No hazard.	0V
	Short		No Hazard.	Decreased
R109	Open		No Hazard.	0V
R124	Open		Normal operation.	
R125	Open		Normal operation.	
R208	Open		No Hazard.	Decreased
SS501	Open	Forward side	-5, -12, -15: Normal operation. -24: F101 opened, No hazard.	-24: 0V
		Flyback side	-5, -12, -15: Normal operation. -24: F101 opened, No hazard.	-24: 0V

## ABNORMAL TEST RESULT

Component	Mode		Comment	Output Voltage
SS501	Short	Forward side	No Hazard.	Decreased
		Flyback side	No Hazard.	Decreased
SS502 Except -24	Open	Forward side	Normal operation.	
		Flyback side	Normal operation.	
	Short	Forward side	No Hazard.	Decreased
		Flyback side	No Hazard.	Decreased
TR103	Short	D-S	No Hazard.	0V
		G-D	Normal operation.	
TR104	Open	C	Normal operation.	
		E	Normal operation.	
		B	Normal operation.	
	Short	E-B	Normal operation.	
TR105	Open	D	No Hazard.	0V
		S	No Hazard.	0V
		G	F101 opened, No hazard.	0V
	Short	D-S	F101 opened, No hazard.	0V
		S-G	No Hazard.	0V
		G-D	F101 opened, No hazard.	0V
TR201	Open	D	No Hazard.	0V
		S	No Hazard.	0V
		G	F101 opened, No hazard.	0V
	Short	D-S	F101 opened, No hazard.	0V
		S-G	No Hazard.	0V
		G-D	F101 opened, No hazard.	0V

ABNORMAL TEST RESULT

Component	Mode	Comment	Output Voltage
ZD103	Open	Normal operation.	